

# Superwand Edge protection tape

Aluminium angle profiles (2 x 14 mm), rolled  
1 reel = 30 m

## Implementation

To protect the soffit edges, we propose to apply the Superwand edge protection tape. This protection tape is composed with a paper backing and two aluminium strips. Cut the edge protection tape to size, folded to shape (paper side out) and fit to edge.

Apply Superwand glue (slightly diluted) to the inner side of the Edge Protection tape and glue on the corner.

This makes the edges resistant to knocks and shocks and you get a clean finish.

**Art. no. 33150**

